




Recovery LOGIC4 - Vehicle Coverage





Recovery – 32 Groves Avenue
Mulgrave
NSW 2756
Phone - +61 (02) 4587 7807

Recovery Diagnostic Dongle – LOGIC4

Recovery LOGIC4 from BMI is a new, innovative and powerful diagnostic tool for Land Rover vehicles which provides workshops and Land Rover owners with market leading diagnostic functionality.

The system works with a smartphone device (Android or iOS) and comes with a unique diagnostic dongle, designed to provide comprehensive workshop diagnostics in a compact and mobile design.

Two versions of the Recovery product are available for purchase, the Recovery LOGIC4 and Recovery LOGIC4 Pro.

Recovery LOGIC4 is targeted at Land Rover owners and enthusiasts and provides support for a single Land Rover model whereas Recovery LOGIC4 Pro is targeted at the workshop and provides coverage for all Land Rover models across all available years.

The Recovery App can be download from the Android Playstore or Apple App Store and is designed to work with a range of smartphone devices, communicating wirelessly to the diagnostic dongle over a Bluetooth connection.

The Recovery dongle is compact in design, and when fitted to the vehicle protrudes only 23mm from the diagnostic socket, it is one of the smallest and most capable diagnostic dongles on the market. The compact design allows the device to be left permanently fitted to the vehicle. The wireless connectivity enables a user to move freely around the vehicle and still view diagnostic information in the palm of their hand.

The system provides diagnostic coverage for Land Rover vehicles from 1987 through to present day and covers all models in the Land Rover range, including:

- Range Rover (Classic, P38, L322 & L405)
- Range Rover Sport
- Range Rover Evoque
- Discovery (Series 1, 2, 3 & 4)
- Discovery Sport
- Defender
- Freelander

The LOGIC4 system has been designed to present complex diagnostic information in a simple and easy to read format, allowing technicians and owners to quickly and easily analyse vehicle faults.

The system provides a range of features from basic diagnostics through to more complex functions such as module replacement, key programming and air suspension calibration etc. The key diagnostic functions available within the Recovery system include:

- ECU Information
- Diagnostic Trouble Codes (Read and Clear)
- Live Data Values (Battery Voltage, Engine Speed etc.)
- Actuators or Forced Outputs (e.g. switching an injector on / off)
- Special Functions (e.g. Key programming)

The LOGIC4 provides support for the majority of control modules and diagnostic functions which you would expect to find on an expensive workshop tool, including but not limited to Engine, ABS, Air Suspension, SRS, Body Control, Climate Control, Infotainment, Instrument Cluster and Transmission Control systems.



Table of Contents V4.0

	Page No.
Range Rover Sport – System Coverage	1 - 2
<u>Range Rover Sport – Special Functions</u>	3 – 5
Range Rover P38 – System Coverage	6
<u>Range Rover P38– Special Functions</u>	6
<u>Range Rover Classic – System Coverage</u>	7
Range Rover – System Coverage	8 - 10
<u>Range Rover - Special Functions</u>	11 -14
Discovery 1 – System Coverage	15
<u>Discovery 1 - Special Functions</u>	15
Discovery 2 – System Coverage	15
<u>Discovery 2 - Special Functions</u>	15



	Page No.
Discovery 3 (LR3) (2005 – 2009) – System Coverage	16
<u>Discovery 3 (LR3) (2005 – 2009) - Special Functions</u>	16
Discovery 4 (LR4) (2010 – 2015) – System Coverage	17 -18
<u>Discovery 4 (LR4) (2010 – 2015) - Special Functions</u>	19 -20
Range Rover Evoque – System Coverage	21
<u>Range Rover Evoque - Special Functions</u>	22
<u>Discovery Sport (2015 -) – System Coverage</u>	23
Freelander 1 – System Coverage	24
<u>Freelander 1 - Special Functions</u>	24
Freelander 2 (LR2) – System Coverage	
<u>25 Freelander 2 (LR2) - Special Functions</u>	26 -27
Defender (1994 – 2012) – System Coverage	28
<u>Defender (1994 – 2012) Special Functions</u>	28

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List			
			System Supported	Basic Function		
Range Rover Sport	2005-2009	Engine	✓	✓		
		AT	✓	✓		
		ABS	✓	✓		
		SRS	✓	✓		
		Air suspension	✓	✓		
		Instrument cluster control module	✓	✓		
		All terrain control module	✓	✓		
		Audio front control module	✓	✓		
		Audio amplifier module	✓	✓		
		Body control module	✓	✓		
		Cellular telephone control module	✓	✓		
		Digital audio control module C	✓	✓		
		Front entertainment control module	✓	✓		
		Front lighting control module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Parking assist control module	✓	✓		
		Parking brake control module	✓	✓		
		Rear entertainment control module	✓	✓		
		Satellite audio unit module	✓	✓		
		Steering angle sensor module	✓	✓		
		Tire pressure monitor module	✓	✓		
		Traffic message channel module	✓	✓		
		Transfer case control module	✓	✓		
		Vehicle dynamics control module	✓	✓		
		Dynamic response module	✓	✓		
		Speed control module	✓	✓		
		Auxiliary heater control module	✓	✓		
			2010-2011	Engine	✓	✓
				Transmission control module	✓	✓
				ABS control module	✓	✓
Restraints control module	✓			✓		
Ride level control module	✓			✓		
Instrument cluster control module	✓			✓		
Parking brake control module	✓			✓		
Body control module	✓			✓		
Steering angle sensor module	✓			✓		
Heating ventilation and air conditioning control module	✓			✓		
Adaptive damping control module	✓			✓		
Parking assist control module	✓			✓		
Vehicle immobilizer control module	✓			✓		
All terrain control module	✓			✓		
Headlamp control module	✓			✓		
Transfer case control module	✓			✓		
Rear differential control module	✓			✓		
Dynamic response module	✓			✓		
Restraints occupant classification system module	✓			✓		
Audio front control module	✓			✓		
Audio amplifier module	✓			✓		
Driver's door module	✓			✓		
Driver's seat module	✓			✓		
Passenger's door module	✓			✓		
Cellular telephone control module	✓			✓		
Front controls interface module(heating ventilation air conditioning controls)	✓			✓		
Front controls interface module B(front audio control panel)	✓			✓		
Front entertainment control module	✓			✓		
Keyless vehicle module	✓			✓		
Headlamp control module B	✓			✓		
Image processing module B	✓	✓				
Rear entertainment control module	✓	✓				
Television module	✓	✓				
	2012-2013	Engine	✓	✓		
		Transmission control module	✓	✓		
		ABS control module	✓	✓		
		Restraints control module	✓	✓		
		Ride level control module	✓	✓		
		Instrument cluster control module	✓	✓		
		Body control module	✓	✓		
		Parking brake control module	✓	✓		
		Parking assist control module	✓	✓		
		Gear shift module	✓	✓		
		Steering angle sensor module	✓	✓		
		Restraints occupant classification system module	✓	✓		
		Auxiliary heater control module	✓	✓		
		Adaptive damping control module	✓	✓		
		Rear differential control module	✓	✓		
		All terrain control module	✓	✓		
		Headlamp control module	✓	✓		
		Dynamic response module	✓	✓		
		Transfer case control module	✓	✓		
		Speed control module	✓	✓		
		Vehicle immobilizer control module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Headlamp control module B	✓	✓		
		Driver's door module	✓	✓		
		Driver's seat module	✓	✓		
		Passenger's door module	✓	✓		
		Rear gate/trunk module	✓	✓		
		Image processing module B	✓	✓		
		Keyless vehicle module	✓	✓		
		Front controls interface module(heating ventilation air conditioning air conditioning controls)	✓	✓		
Front controls interface module B(front audio control panel)	✓	✓				
Accessory protocol interface module	✓	✓				
Front control/display interface module(high level display front)	✓	✓				
Navigation control module	✓	✓				
Audio amplifier module	✓	✓				
Audio front control module	✓	✓				
Digital audio broadcast module	✓	✓				
Rear entertainment control module	✓	✓				
Satellite audio unit module	✓	✓				
Television module	✓	✓				

Recovery System Coverage V4.0

			Coverage List	
Model	Year	Vehicle System	System Supported	Basic Function
	2014-2015	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Instrument cluster control module	✓	✓
		Body control module	✓	✓
		Chassis control module	✓	✓
		Chassis control module B	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Steering angle sensor module	✓	✓
		Power steering control module	✓	✓
		Speed control module	✓	✓
		Gateway module	✓	✓
		Gear shift module	✓	✓
		Headlamp control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Rear differential control module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Telematic control unit module	✓	✓
		General proximity sensor module	✓	✓
		Battery energy control module	✓	✓
		Electric power inverter converter module	✓	✓
		Safety belt pretensioner control module A - drivers side	✓	✓
		Safety belt pretensioner control module B - passengers side	✓	✓
		Vehicle immobilizer control module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module "B"(front audio control panel)	✓	✓
		Front controls interface module "C"(front audio control panel)	✓	✓
		Headlamp control module "B"	✓	✓
		Image processing module "B"	✓	✓
		Keyless vehicle module	✓	✓
		Passenger's door module	✓	✓
		Passenger's seat module	✓	✓
		Running board control module	✓	✓
		Rear gate/trunk module	✓	✓
		Rear Heating ventilation and air conditioning control module	✓	✓
		Rear left - Seat module	✓	✓
		Rear right - Seat module	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
		Head-up display cooling fan module	✓	✓
		Connect and view module	✓	✓
		Head up display	✓	✓
		Navigation control module	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Digital audio broadcast module	✓	✓
		Navigation control module	✓	✓
		Rear entertainment control module	✓	✓
		Satellite audio unit module	✓	✓
		Television module	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover Sport	2005 - 2009	Powertrain control module	Adaption clear
		Powertrain control module	Idle speed test
		Powertrain control module	Purge valve self test
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Fuel prime routine
		Transmission control module	Adaption clear
		Supplemental Inflatable Restraint System	Seat cushion replacement
		Supplemental Inflatable Restraint System	Third button configuration
		Instrument cluster control module	Service interval reset
		Instrument cluster control module	Vehicle reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Ride level control module	Suspension tight tolerance control
		Ride level control module	Set/un - set air suspension geometry set - up
		Ride level control module	Ride level control module inflation (showroom)
		Body control module	Rain sensor initialisation
		Body control module	Sliding roof module initialisation
		Body control module	Driver's memory seat calibration
		Body control module	Steering column calibration
		Vehicle dynamics control module	Brake bleed
		Steering angle sensor module	Steering wheel angle sensor calibration
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Parking assist control module	Front parking aid sensors 'Auto - On' activation
		Auxiliary heater control module	Auxiliary heater fuel delivery test
		Auxiliary heater control module	Auxiliary heater priming routine
		Auxiliary heater control module	Auxiliary heater activation test
		Transfer case control module	Stepper motor replacement
Transfer case control module	Absolute position sensor replacement		
Transfer case control module	Solenoid replacement		
Range Rover Sport	2010 - 2011	Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Injector replacement
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Security - Keyfob remote functionality
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Adaption clear
		Transmission control module	Adaption clear
		Anti-lock Braking System	Brake bleed
		Anti-lock Braking System	Yaw Rate sensor calibration
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Sunroof calibration
		Body control module	Valet mode reset
		Heating ventilation and air conditioning control module	Evaporator and heater test
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Vehicle dynamics control module	Brake bleed
		Steering angle sensor module	Steering wheel angle sensor calibration
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Auxiliary heater control module	Auxiliary heater fuel delivery test
		Auxiliary heater control module	Auxiliary heater priming routine
		Auxiliary heater control module	Auxiliary heater activation test
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Driver's seat module	Seat entry/exit enable
		Passenger's door module	Passenger's door window glass calibration
Adaptive damping control module	Build mode		
Rear differential control module	Control module calibration		
Restraints occupant classification system module	Seat cushion replacement		
Headlamp Control Module	Headlamp control module system calibration		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover Sport	2012 - 2013	Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Rest of world - Service interval options
		Transmission control module	Adaption clear
		Anti-lock Braking System	Brake bleed
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Service interval reset
		Instrument cluster control module	Vehicle reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Ride level control module	Set/un - set air suspension geometry set - up
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Steering column calibration
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Tire pressure monitoring tire pressure sensor test
		Vehicle dynamics control module	Brake bleed
		Steering angle sensor module	Steering wheel angle sensor calibration
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Auxiliary heater control module	Auxiliary heater activation test
		Passenger's door module	Passenger's door window glass calibration
		Transfer case control module	Absolute position sensor replacement
		Adaptive damping control module	Build mode
		Speed control module	Speed control alignment
		Restraints occupant classification system module	Seats - Seat cover replacement
		Headlamp Control Module	Headlamp control module system calibration
		Keyless vehicle module	Check all antennas
		Keyless vehicle module	Check passive keys enabled
		Audio amplifier module	DVD region counter reset
		Audio amplifier module	Calibrate dynamic volume control
		Rear gate/trunk module	Tailgate/trunk calibration
		Image processing module B	Camera auto learn routine
		Powertrain control module	Adaption clear
Powertrain control module	Idle speed - Adjustment		
Powertrain control module	Service history data		
Vehicle dynamics control module	Brake bleed		
Parking brake control module	Drive the parking brake to the mounting position		
Parking brake control module	Drive the parking brake to the latching position		
Parking brake control module	Parking brake unjam procedure		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover Sport	2014 - 2015	Powertrain control module	Service interval reset
		Powertrain control module	Adaption clear
		Powertrain control module	Fuel prime routine
		Powertrain control module	Throttle valve actuator replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Injector replacement
		Powertrain control module	Diesel fueling adaption re - initialization
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Rest of world - Service interval options
		Powertrain control module	Fuel Lift Pump
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Vehicle reset
		Ride level control module	Set/un - set air suspension geometry set - up
Body control module	Verify Keys		
Body control module	Sunroof calibration		
Body control module	Tire pressure sensor replacement		
Body control module	Valet mode reset		
Body control module	Steering column calibration		
Body control module	Tire pressure monitor sensor identification display		
Body control module	Fuel pump supply - Enable/disable		
Body control module	Transportation mode		
Auxiliary heater control module	Air suspension deflation		
Auxiliary heater control module	Air suspension enable		
Auxiliary heater control module	Height recalibration		
Auxiliary heater control module	Set/un - set air suspension tight tolerance mode (headlamp setting)		
Heating ventilation and air conditioning control module	Reset compressor protection counter		
Heating ventilation and air conditioning control module	Seat climate control module calibration		
Heating ventilation and air conditioning control module	Actuators end stop detection		
Heating ventilation and air conditioning control module	Stepper motor initialisation		
Vehicle dynamics control module	Brake bleed		
Tire pressure monitor module	Tire pressure sensor replacement		
Tire pressure monitor module	Tire pressure monitor confirmation application		
Parking brake control module	Longitudinal accelerometer calibration		
Parking brake control module	Parking brake pad replacement - Release to service position		
Parking brake control module	Parking brake pad replacement - Exit maintenance mode application		
Parking brake control module	Parking brake activation		
Passenger's seat module	Power steering soft - lock end stops reset routine		
Parking assist control module	Parking aid switch-Enable/disable		
Auxiliary heater control module	Auxiliary heater priming routine		
Gateway module	Quiescent current control module internal check		
Gateway module	Battery replacement		
Driver's door module	Driver's door window glass calibration		
Driver's seat module	Driver's seat calibration		
Passenger's door module	Passenger's door window glass calibration		
Passenger's seat module	Passenger's seat calibration		
Adaptive damping control module	Build mode		
Speed control module	Speed control alignment		
Rear differential control module	Control module calibration		
Running board control module	Service mode enabled		
Running board control module	Service mode disabled		
Restraints occupant classification system module	Seats - Seat cover replacement		
Keyless vehicle module	Recover programmed keys		
Keyless vehicle module	Check all antennas		
Keyless vehicle module	Check passive keys enabled		
Audio amplifier module	Calibrate dynamic volume control		
Rear gate/trunk module	Tailgate/trunk calibration		
Image processing module B	Camera auto learn routine		
Audio front control module	Navigation reset		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Range Rover P38	1994 - 2002	WABCO D TYPE ABS	✓	✓
		WABCO C TYPE ABS	✓	✓
		LUCAS EAS AIR SUSPENSION	✓	✓
		TRW MPS (TYPE 1) AIRBAG	✓	✓
		TRW SPS (TYPE 2) AIRBAG	✓	✓
		BECM	✓	✓
		VALEO HEVAC	✓	✓
		HELLA CRUISE CONTROL	✓	✓
		Lucas GEMS EMS	✓	✓
		BOSCH MOTRONIC M5 2.1 EMS	✓	✓
		BOSCH AUTO BOX GS8.87.1	✓	✓
		BOSCH AUTO BOX GS8.87.0	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover(P38)	1995 - 2001	Anti-lock Braking System	ECU Replacement
		Anti-lock Braking System	Brake Bleeding
		Air Suspension	Transport Mode
		Air Suspension	High Lock Mode
		Air Suspension	Adjust Heights : Raise Fully
		Air Suspension	Adjust Heights : Lower Fully
		Air Suspension	Adjust Heights : Adjust To High Profile
		Air Suspension	Adjust Heights : Adjust To Standard
		Air Suspension	Adjust Heights : Adjust To Low Profile
		Air Suspension	Adjust Heights : Adjust To Access
		Air Suspension	Calibrate
		Air Suspension	Deflate System
		Body Control	Odomter Update
		Climate Control	Perform Servo Tune
		Climate Control	Replace ECU
		Cruise Control	Tune Information
		Cruise Control	Last Shut Off
		Engine(M5 2.1 EMS)	Immobilisation Reprogram
		Engine(M5 2.1 EMS)	LEV1 1.0mm Evap Leak Test
		Engine(M5 2.1 EMS)	LEV2 0.5mm Leak Tracing
		Engine(M5 2.1 EMS)	Reset Adaptions
		Engine(M5 2.1 EMS)	Repair Validation
		Engine(M5 2.1 EMS)	Open Loop Tune
		Engine(M5 2.1 EMS)	Programming History
		Engine(M5 2.1 EMS)	ECU Checks & Renewal
		Engine(M5 2.1 EMS)	Non Start Diagnostics
		Transmission	Reset Adaptions
		Transmission	Read VIN
		Transmission	Program VIN
		Transmission	Read Tune Select
Transmission	Program Tune Select		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Range Rover Classic	1994	WABCO C TYPE C ABS	✓	✓
		TRW MPS (TYPE 1) AIRBAG	✓	✓
		EMD 14CUX (LUCAS HOTWIRE)	✓	✓

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List			
			System Supported	Basic Function		
Range Rover L322	2002 - 2005	BOSCH DSC 5.7 ABS	✓	✓		
		WABCO EAS Air Suspension	✓	✓		
		MRS 4 Airbag	✓	✓		
		EWS 3D Immobiliser	✓	✓		
		GM3 BCU Body Controller	✓	✓		
		BOSCH ME7.2 EMS	✓	✓		
		WEBASTO FUEL BURNING HEATER	✓	✓		
		HEVAC	✓	✓		
		Instrument Pack	✓	✓		
		Light Check Module	✓	✓		
		Memory Seats	✓	✓		
		Multi Function Seats	✓	✓		
		Digital Sound Processor	✓	✓		
		Park Distace Control	✓	✓		
		SIEMENS Transfer Box	✓	✓		
		BOSCH Auto box GS8.60.1	✓	✓		
		SIEMENS Auto Gerbox	✓	✓		
		Range Rover L322	2006	Engine	✓	✓
				Auto Gearbox	✓	✓
				Vehicle dynamics control module	✓	✓
SRS	✓			✓		
Instrument cluster control module	✓			✓		
Ride level control module(Air suspension)	✓			✓		
Body Processor Module	✓			✓		
Steering Angle Sensor	✓			✓		
Tire pressure monitor module	✓			✓		
Parking brake control module	✓			✓		
Driver's seat module	✓			✓		
Heating ventilation and air conditioning control module	✓			✓		
Parking aid control module	✓			✓		
Rain Sensor	✓			✓		
Steering Lock Module	✓			✓		
Light check module	✓			✓		
Auxiliary heater control module	✓			✓		
Running board control module	✓			✓		
Audio amplifier module	✓			✓		
Front entertainment control module	✓			✓		
All terrain control module	✓			✓		
Restraints occupant classification system module	✓			✓		
Transfer case control module	✓			✓		
Vehicle immobilizer control module	✓			✓		
Audio front control module	✓			✓		
Rear entertainment control module	✓			✓		
Satellite audio unit module	✓			✓		
Cellular telephone control module	✓			✓		
Traffic message channel module	✓			✓		
Television module	✓			✓		
Range Rover L322	2007-2009			Engine	✓	✓
				AT	✓	✓
				ABS	✓	✓
				SRS	✓	✓
				Instrument cluster control module	✓	✓
				Ride level control module(Air suspension)	✓	✓
				Tire pressure monitor module	✓	✓
				Parking brake control module	✓	✓
				Audio amplifier module	✓	✓
				Front lighting control module	✓	✓
				Front entertainment control module	✓	✓
				Parking aid control module	✓	✓
		CD Player	✓	✓		
		All terrain control module	✓	✓		
		Driver's climate seat module	✓	✓		
		Rear heating ventilation and air conditioning control module	✓	✓		
		Restraints control module(SRS)	✓	✓		
		Restraints occupant classification system module	✓	✓		
		Steering angle sensor module	✓	✓		
		Transfer case control module	✓	✓		
		Transmission control module	✓	✓		
		Vehicle dynamics control module(ABS)	✓	✓		
		Vehicle immobilizer control module	✓	✓		
		Rear differential control module	✓	✓		
		Auxiliary heater control module	✓	✓		
		Audio front control module	✓	✓		
		Rear entertainment control module	✓	✓		
		Satellite audio unit module	✓	✓		
		Cellular telephone control module	✓	✓		
		Traffic message channel module	✓	✓		
		Television module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Light check module	✓	✓		
		Steering Lock Module	✓	✓		
		Body Processor Module	✓	✓		
		Driver's seat module	✓	✓		
		Rain Sensor	✓	✓		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
	2010-2012	Engine	✓	✓
		Transmission control module	✓	✓
		ABS	✓	✓
		Restraints control module	✓	✓
		Instrument cluster control module	✓	✓
		Ride level control module	✓	✓
		Body control module	✓	✓
		Steering angle sensor module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Gear shift module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Adaptive damping control module	✓	✓
		Rear differential control module	✓	✓
		Rear Heating ventilation and air conditioning control module	✓	✓
		Speed control module	✓	✓
		Side object detection control module-Right	✓	✓
		Side object detection control module-Left	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Passenger's door module	✓	✓
		Passenger's seat module	✓	✓
		Restraints occupant classification system module	✓	✓
		Headlamp control module	✓	✓
		Keyless vehicle module	✓	✓
		Running board control module	✓	✓
		Audio front control module	✓	✓
		Audio amplifier module	✓	✓
		CD player/changer module	✓	✓
		Front entertainment control module	✓	✓
		Cellular telephone control module	✓	✓
		Satellite audio unit module	✓	✓
		Digital audio broadcast module	✓	✓
		Digital audio control module C	✓	✓
		Rear climate seat module	✓	✓
		Remote driver utility module	✓	✓
		Television module	✓	✓
		Driver's climate seat module	✓	✓
		Headlamp control module B	✓	✓
		Image processing module B	✓	✓
		Rear entertainment control module	✓	✓

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Range Rover L405	2013	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Instrument cluster control module	✓	✓
		Chassis control module	✓	✓
		Chassis control module B	✓	✓
		Body control module	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Steering angle sensor module	✓	✓
		Power steering control module	✓	✓
		Speed control module	✓	✓
		Gateway module	✓	✓
		Gear shift module	✓	✓
		Headlamp control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Rear differential control module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Safety belt pretensioner control module A - drivers side	✓	✓
		Safety belt pretensioner control module B - passengers side	✓	✓
		Vehicle immobilizer control module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Driver's climate seat module	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module "B"(front audio control panel)	✓	✓
		Front controls interface module "C"(front audio control panel)	✓	✓
		Headlamp control module "B"	✓	✓
		Image processing module "B"	✓	✓
		Keyless vehicle module	✓	✓
		Passenger's door module	✓	✓
		Passenger's seat module	✓	✓
		Running board control module	✓	✓
		Rear climate seat module	✓	✓
		Rear gate/trunk module	✓	✓
		Lower - Rear gate/trunk module	✓	✓
		Rear Heating ventilation and air conditioning control module	✓	✓
		Rear left - Seat module	✓	✓
		Rear right - Seat module	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Digital audio broadcast module	✓	✓
		Navigation control module	✓	✓
		Rear entertainment control module	✓	✓
		Satellite audio unit module	✓	✓
		Television module	✓	✓

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
	2014-2015	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Instrument cluster control module	✓	✓
		Body control module	✓	✓
		Chassis control module	✓	✓
		Chassis control module B	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Steering angle sensor module	✓	✓
		Power steering control module	✓	✓
		Speed control module	✓	✓
		Gateway module	✓	✓
		Gear shift module	✓	✓
		Headlamp control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Rear differential control module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Telematic control unit module	✓	✓
		General proximity sensor module	✓	✓
		Battery energy control module	✓	✓
		Electric power inverter converter module	✓	✓
		Safety belt pretensioner control module A - drivers side	✓	✓
		Safety belt pretensioner control module B - passengers side	✓	✓
		Vehicle immobilizer control module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module "B"(front audio control panel)	✓	✓
		Front controls interface module "C"(front audio control panel)	✓	✓
		Headlamp control module "B"	✓	✓
		Image processing module "B"	✓	✓
		Keyless vehicle module	✓	✓
		Passenger's door module	✓	✓
		Passenger's seat module	✓	✓
		Running board control module	✓	✓
		Rear gate/trunk module	✓	✓
		Lower - Rear gate/trunk module	✓	✓
		Rear Heating ventilation and air conditioning control module	✓	✓
		Rear left - Seat module	✓	✓
		Rear right - Seat module	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
		Head-up display cooling fan module	✓	✓
		Connect and view module	✓	✓
		Calf rest table module	✓	✓
		Head up display	✓	✓
		Navigation control module	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Digital audio broadcast module	✓	✓
		Navigation control module	✓	✓
		Rear entertainment control module	✓	✓
		Satellite audio unit module	✓	✓
		Television module	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions			
Model	Year	System	Supported		
Range Rover	2002 - 2005	Anti-lock Braking System	ECU Renewal		
		Anti-lock Braking System	Brake Bleeding		
		Anti-lock Braking System	Steering Angle Calibration		
		Anti-lock Braking System	Steering Angle Sensor Renewal		
		Anti-lock Braking System	Brake Assist Sensitivity		
		Air Suspension	ECU Renewal		
		Air Suspension	Height Recalibration		
		Air Suspension	Deflation : Front Left Bellow Valve		
		Air Suspension	Deflation : Front Right Bellow Valve		
		Air Suspension	Deflation : Rear Left Bellow Valve		
		Air Suspension	Deflation : Rear Right Bellow Valve		
		Air Suspension	Deflation : Exhaust Valve		
		Air Suspension	Inflation		
		Air Suspension	Headlight Calibration		
		Airbag	ECU Renewal		
		Alarms/Security	ECU Renewal		
		Alarms/Security	Immobilisation Learn (Synchronise Immobilisation)		
		Alarms/Security	Identify Key		
		Alarms/Security	Key Store		
		Alarms/Security	Key Programming		
		Body Control	ECU Renewal		
		Body Control	Identify Keys		
		Body Control	ECU Code		
		Body Control	Rain Sensor Reset		
		Body Control	Initialise Sunroof		
		Body Control	Information Memory		
		Engine(ME7.2 EMS)	ECU Checks And Renewal		
		Engine(ME7.2 EMS)	Immobilisation Learn		
		Engine(ME7.2 EMS)	Reset Adaptions		
		Engine(ME7.2 EMS)	Idle CO Adjust		
		Engine(ME7.2 EMS)	Erase Driver Demand Fault		
		Engine(ME7.2 EMS)	Secondary Air Test		
		Engine(ME7.2 EMS)	Purge Valve Test		
		Engine(ME7.2 EMS)	VCC Test 1		
		Engine(ME7.2 EMS)	Idle Speed Test		
		Engine(TD6)	ECU Checks & Renewal		
		Engine(TD6)	Immobilisation Learn		
		Engine(TD6)	Idle Speed		
		Engine(TD6)	HFM Sensor		
		Engine(TD6)	Reset Adaptions		
		Engine(TD6)	Injector Grade Compensation		
		Fuel Burning Heater	ECU Renewal		
		Fuel Burning Heater	Prime System		
		Heater electron ventilation air conditioning	ECU Renewal		
		Instrumentation	ECU Renewal		
		Instrumentation	Pack Language		
		Instrumentation	Service Reset		
		Exterior Lighting	ECU Renewal		
Information Systems	ECU Renewal				
Parking Aid	ECU Renewal				
Transfer Box	ECU Renewal				
Transfer Box	Calibration				
Transmission	ECU Renewal				
Transmission	Reset Adaptions				
Range Rover	2006	Powertrain control module	Adaption clear		
		Powertrain control module	Purge valve self test		
		Powertrain control module	OBDII readiness tests		
		Instrument cluster control module	Service interval reset		
		Ride level control module	Air suspension height calibration		
		Ride level control module	Air suspension deflation		
		Ride level control module	Air suspension enable		
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode		
		Ride level control module	Set/un - set air suspension geometry set - up		
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)		
		Ride level control module	Suspension tight tolerance control		
		Body control module	Sliding roof module initialisation		
		Tire pressure monitor module	Tire pressure sensor replacement		
		Tire pressure monitor module	Tire pressure monitor confirmation application		
		Parking brake control module	Drive the parking brake to the mounting position		
		Parking brake control module	Drive the parking brake to the latching position		
		Parking brake control module	Longitudinal accelerometer sensor calibration		
		Parking brake control module	Parking brake unjam procedure		
		Transfer case control module	Stepper motor replacement		
		Transfer case control module	Solenoid replacement		
		Rain Sensor	Rain sensor initialisation		
		Rain Sensor	Rain sensor windshield setup		
		Running board control module	Service mode enabled		
		Running board control module	Service mode disabled		
		Restraints occupant classification system module	Seat cushion replacement		
		Transmission control module	Adaption clear		
		Vehicle dynamics control module	Brake bleed		
		Steering angle sensor module	Steering wheel angle sensor calibration		
		Range Rover	2007 - 2009	Powertrain control module	Adaption clear
				Powertrain control module	Idle speed test
				Powertrain control module	Purge valve self test
				Powertrain control module	OBDII readiness tests
Powertrain control module	Diesel particulate filter dynamic regeneration				
Powertrain control module	Diesel particulate filter replacement				
Powertrain control module	Fuel Prime Routine				
Transmission control module	Adaption clear				
Instrument cluster control module	Service interval reset				
Ride level control module	Air suspension height calibration				
Ride level control module	Air suspension deflation				
Ride level control module	Air suspension enable				
Ride level control module	Set/un - set air suspension manufacturing/freeze mode				
Ride level control module	Set/un - set air suspension geometry set - up				
Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)				
Ride level control module	Suspension tight tolerance control				
Body control module	Sliding roof module initialisation				
Vehicle dynamics control module	Brake bleed				
Steering angle sensor module	Steering wheel angle sensor calibration				
Tire pressure monitor module	Tire pressure sensor replacement				
Tire pressure monitor module	Tire pressure monitor confirmation application				
Parking brake control module	Drive the parking brake to the mounting position				
Parking brake control module	Drive the parking brake to the latching position				
Parking brake control module	Longitudinal accelerometer sensor calibration				
Parking brake control module	Parking brake unjam procedure				
Transfer case control module	Stepper motor replacement				
Transfer case control module	Solenoid replacement				
Rain Sensor	Rain sensor initialisation				
Rain Sensor	Rain sensor windshield setup				
Running board control module	Service mode enabled				
Running board control module	Service mode disabled				
Restraints occupant classification system module	Seat cushion replacement				

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover	2007 - 2009	Powertrain control module	Idle speed - Adjustment
		Powertrain control module	Oil service counter reset
		Powertrain control module	Adaption clear
		Powertrain control module	Idle speed - Adjustment
		Transmission control module	Adaption clear
		Anti-lock Braking System	Brake bleed
		Anti-lock Braking System	Yaw Rate sensor calibration
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Build mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Sunroof calibration
		Body control module	Valet mode reset
		Heating ventilation and air conditioning control module	Evaporator and heater test
		Vehicle dynamics control module	Brake bleed
		Steering angle sensor module	Steering wheel angle sensor calibration
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Passenger's door module	Passenger's door window glass calibration
		Rain Sensor	Rain sensor initialisation
		Rain Sensor	Rain sensor windshield setup
		Running board control module	Service mode enabled
		Running board control module	Service mode disabled
		Restraints occupant classification system module	Seat cushion replacement
Restraints occupant classification system module	Seat cushion replacement		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover	2013	Powertrain control module	Fuel prime routine
		Powertrain control module	Adaption status
		Powertrain control module	Throttle valve actuator replacement
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Rest of world - Service interval options
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Injector replacement
		Powertrain control module	Fuel Lift Pump
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Service interval reset
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Transmission control module	Adaption clear
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Vehicle reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Build mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Steering column calibration
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Fuel pump supply - Enable/disable
		Body control module	Sunroof calibration
		Body control module	Valet mode reset
		Body control module	Transportation mode
		Body control module	Verify Keys
		Body control module	Tire pressure monitoring tire pressure sensor test
		Auxiliary heater control module	Air suspension height calibration
		Auxiliary heater control module	Air suspension deflation
		Auxiliary heater control module	Air suspension enable
		Auxiliary heater control module	Set/un - set air suspension manufacturing/freeze mode
		Auxiliary heater control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Auxiliary heater control module	Set/un - set air suspension geometry set - up
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Heating ventilation and air conditioning control module	Auxiliary heater priming routine
		Heating ventilation and air conditioning control module	Reset compressor protection counter
		Vehicle dynamics control module	Brake bleed
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Parking brake pad replacement - Release to service position
		Parking brake control module	Parking brake pad replacement - Exit maintenance mode application
		Parking brake control module	Parking brake activation
		Parking brake control module	Longitudinal accelerometer calibration
		Parking brake control module	Brake caliper replacement assembly test
		Passenger's seat module	Power steering soft - lock end stops reset routine
		Gateway module	Test dual battery system
		Gateway module	Battery replacement
		Gateway module	Quiescent current control module internal check
		Gateway module	Verify secondary battery charging
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Passenger's door module	Passenger's door window glass calibration
		Passenger's seat module	Passenger's seat calibration
		Transfer case control module	Absolute position sensor replacement
		Transfer case control module	Motor replacement
		Speed control module	Speed control alignment
		Rain Sensor	Rain sensor initialisation
		Rain Sensor	Rain sensor windshield setup
		Running board control module	Service mode enabled
		Running board control module	Service mode disabled
		Restraints occupant classification system module	Seats - Seat cover replacement
		Headlamp Control Module	Headlamp control module system calibration
		Keyless vehicle module	Check all antennas
		Keyless vehicle module	Check passive keys enabled
		Keyless vehicle module	Keyless latch configuration
		Audio amplifier module	DVD region counter reset
		Audio amplifier module	Calibrate dynamic volume control
		Image processing module B	Camera auto learn routine
		Audio front control module	Navigation reset
		Side object detection control module - Left	Side object detection mode history

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover	2014 - 2015	Powertrain control module	Adaption clear
		Powertrain control module	Fuel prime routine
		Powertrain control module	Oil service counter reset
		Powertrain control module	Throttle valve actuator replacement
		Powertrain control module	Injector replacement
		Powertrain control module	Diesel fueling adaption re - initialization
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Fuel Lift Pump
		Powertrain control module	Injector replacement
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Vehicle reset
		Ride level control module	Set/un - set air suspension geometry set - up
		Body control module	Sunroof calibration
		Body control module	Tire pressure sensor replacement
		Body control module	Valet mode reset
		Body control module	Steering column calibration
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Fuel pump supply - Enable/disable
		Body control module	Transportation mode
		Body control module	Verify Keys
		Body control module	Calf rest calibration
		Auxiliary heater control module	Air suspension deflation
		Auxiliary heater control module	Air suspension enable
		Auxiliary heater control module	Set/un - set air suspension manufacturing/freeze mode
		Auxiliary heater control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Reset compressor protection counter
		Heating ventilation and air conditioning control module	Seat climate control module calibration
		Vehicle dynamics control module	Brake bleed
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Longitudinal accelerometer calibration
		Parking brake control module	Parking brake pad replacement - Release to service position
		Parking brake control module	Parking brake pad replacement - Exit maintenance mode application
		Parking brake control module	Parking brake activation
		Passenger's seat module	Power steering soft - lock end stops reset routine
		Parking assist control module	Parking aid switch-Enable/disable
		Gateway module	Quiescent current control module internal check
		Driver's seat module	Driver's seat calibration
		Passenger's seat module	Passenger's seat calibration
		Speed control module	Speed control alignment
		Rear differential control module	Control module calibration
		Rain Sensor	Rain sensor initialisation
		Rain Sensor	Rain sensor windshield setup
		Running board control module	Service mode enabled
		Running board control module	Service mode disabled
Restraints occupant classification system module	Seats - Seat cover replacement		
Headlamp Control Module	Headlamp control module system calibration		
Keyless vehicle module	Check all antennas		
Keyless vehicle module	Recover programmed keys		
Gateway module	Battery replacement		
Audio amplifier module	DVD region counter reset		
Rear gate/trunk module	Tailgate/trunk calibration		
Audio front control module	Navigation reset		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Discovery 1	1996 - 1998	WABCO C TYPE ABS	✓	✓
		TRW MPS (TYPE 1) AIRBAG	✓	✓
		LUCAS 10AS ALARM	✓	✓
		LUCAS GEMS EMS	✓	✓
		14CUX (LUCAS HOTWIRE) EMS	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Discovery 1	1996 - 1999	Engine(MEMS 1.9)	Immobilisation Reprogram
		Engine(MEMS 1.9)	Service Ignition Offset
		Engine(MEMS 1.9)	Service Idle Speed Offset
		Engine(MEMS 1.9)	Reset Adaptions
		Anti-lock Braking System	Read ECU Configuration

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Discovery 2	1998 - 2004	WABCO SLABS ABS & EAS	✓	✓
		LUCAS ACE	✓	✓
		TRW SPS TYPE 2A AIRBAG	✓	✓
		VALEO BCU	✓	✓
		HELLA CRUISE CONTROL	✓	✓
		BOSCH MOTRONIC M5 2.1 EMS	✓	✓
		WABASTO FUEL BURNING HEATER	✓	✓
		BOSCH AUTO BOX GS8.87.0	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Discovery 2	1999 - 2004	Anti-lock Braking System	Brake Bleeding
		Anti-lock Braking System	ECU Replacement
		Anti-lock Braking System	Differential Lock
		Anti-lock Braking System	Suspension Configuration
		Anti-lock Braking System	SLS Transportation
		Anti-lock Braking System	SLS Calibration
		Anti-lock Braking System	SLS Deflation
		Active Cornering Enhancement	New ECU
		Active Cornering Enhancement	Calibrate ACE System
		Active Cornering Enhancement	Bleed System
		Airbag	Program VIN
		Body Control	EKA Display
		Body Control	Flip Programming
		Body Control	Mobilisation Learn
		Body Control	Alarm Triggers
		Cruise Control	Tune Information
		Cruise Control	Last Shut Off
		Engine(M5 2.1 EMS)	Immobilisation Reprogram
		Engine(M5 2.1 EMS)	LEV1 1.0mm Evap Leak Test
		Engine(M5 2.1 EMS)	LEV2 0.5mm Leak Tracing
		Engine(M5 2.1 EMS)	Reset Adaptions
		Engine(M5 2.1 EMS)	Repair Validation
		Engine(M5 2.1 EMS)	Open Loop Tune
		Engine(M5 2.1 EMS)	Programming History
		Engine(M5 2.1 EMS)	ECU Checks & Renewal
		Engine(M5 2.1 EMS)	Non Start Diagnostics
		Engine(M5 2.1 EMS)	NAS/EU3 OBDII Support
		Engine(TDS)	Security Status
		Engine(TDS)	Read/Set Injector Codes
		Engine(TDS)	Security Reprogram
		Engine(TDS)	ECM Checks & Renewal
		Engine(TDS)	Set 2/3 Track Pedal Pot
		Fuel Burning Heater	Set CO2 Level
		Fuel Burning Heater	Prime System
		Transmission	Reset Adaptions
		Transmission	Read VIN
		Transmission	Program VIN
		Anti-lock Braking System	Brake Bleeding

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Discovery 3	2005-2009	Engine	✓	✓
		AT	✓	✓
		ABS	✓	✓
		SRS	✓	✓
		Instrument cluster control module	✓	✓
		Ride level control module(Air suspension)	✓	✓
		AC	✓	✓
		All terrain control module	✓	✓
		Audio front control module	✓	✓
		Body control module	✓	✓
		Front lighting control module	✓	✓
		Parking assist control module	✓	✓
		Steering angle sensor module	✓	✓
		Transfer case control module	✓	✓
		Auxiliary heater control module	✓	✓
		Digital audio control module C	✓	✓
		Parking brake control module	✓	✓
		Transmission control module	✓	✓
		Vehicle dynamics control module(ABS)	✓	✓
		Tire pressure monitor module	✓	✓
		Rear differential control module	✓	✓
		Speed control module	✓	✓
		Television module	✓	✓
		Satellite audio unit module	✓	✓
		Cellular telephone control module	✓	✓
		Rear entertainment control module	✓	✓
		Front entertainment control module	✓	✓
		Traffic message channel module	✓	✓
		Audio amplifier module	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Discovery 3	2005 - 2009	Powertrain control module	Idle speed test
		Powertrain control module	Purge valve self test
		Powertrain control module	OBDII readiness tests
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Fuel prime routine
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Transmission control module	Adaption clear
		Supplemental Inflatable Restraint System	Seats - Seat cover replacement
		Instrument cluster control module	Service interval reset
		Instrument cluster control module	Vehicle reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Ride level control module	Suspension tight tolerance control
		Ride level control module	Set/un - set air suspension geometry set - up
		Ride level control module	Ride level control module inflation (showroom)
		Body control module	Rain sensor initialisation
		Body control module	Sliding roof module initialisation
		Body control module	Driver's memory seat calibration
		Vehicle dynamics control module	Brake bleed
		Steering angle sensor module	Steering wheel angle sensor calibration
		Tire pressure monitor module	Tire pressure sensor replacement
		Tire pressure monitor module	Tire pressure monitor confirmation application
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Parking assist control module	Front parking aid sensors 'Auto - On' activation
		Auxiliary heater control module	Auxiliary heater fuel delivery test
		Auxiliary heater control module	Auxiliary heater priming routine
		Transfer case control module	Stepper motor replacement
		Transfer case control module	Solenoid replacement
		Transfer case control module	Adaption status
		Transfer case control module	Absolute position sensor replacement

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Discovery 4	2010-2011	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Ride level control module	✓	✓
		Instrument cluster control module	✓	✓
		Body control module	✓	✓
		Steering angle sensor module	✓	✓
		Rear differential control module	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Gear shift module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Headlamp control module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Auxiliary heater control module	✓	✓
		Keyless vehicle module	✓	✓
		Headlamp control module B	✓	✓
		Image processing module B	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Passenger's door module	✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module B(front audio control panel)	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Audio head unit	✓	✓
		Television module	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Rear entertainment control module	✓	✓
		Navigation control module	✓	✓
		Digital audio broadcast module	✓	✓
		Satellite audio unit module	✓	✓
	2012-2013	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Ride level control module	✓	✓
		Instrument cluster control module	✓	✓
		Body control module	✓	✓
		Steering angle sensor module	✓	✓
		Rear differential control module	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Gear shift module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Headlamp control module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Auxiliary heater control module	✓	✓
		Keyless vehicle module	✓	✓
		Headlamp control module B	✓	✓
		Image processing module B	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Passenger's door module	✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module B(front audio control panel)	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Audio head unit	✓	✓
		Television module	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Rear entertainment control module	✓	✓
		Navigation control module	✓	✓
		Digital audio broadcast module	✓	✓
		Satellite audio unit module	✓	✓

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
	2014-15	Engine	✓	✓
		Transmission control module	✓	✓
		ABS control module	✓	✓
		Restraints control module	✓	✓
		Ride level control module	✓	✓
		Instrument cluster control module	✓	✓
		Body control module	✓	✓
		Steering angle sensor module	✓	✓
		Rear differential control module	✓	✓
		Parking brake control module	✓	✓
		Parking assist control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Gear shift module	✓	✓
		Transfer case control module	✓	✓
		All terrain control module	✓	✓
		Headlamp control module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Speed control module	✓	✓
		Gateway module	✓	✓
		General proximity sensor module	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Auxiliary heater control module	✓	✓
		Keyless vehicle module	✓	✓
		Headlamp control module B	✓	✓
		Image processing module B	✓	✓
		Driver's door module	✓	✓
		Driver's seat module	✓	✓
		Passenger's door module	✓	✓
		Connect and view module	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
			✓	✓
		Front controls interface module(heating ventilation air conditioning controls)	✓	✓
		Front controls interface module B(front audio control panel)	✓	✓
		Front control/display interface module(high level display front)	✓	✓
		Audio head unit	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Rear entertainment control module	✓	✓
		Navigation control module	✓	✓
		Digital audio broadcast module	✓	✓
		Satellite audio unit module	✓	✓
		Television module	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Discovery 4	2010 - 2011	Powertrain control module	Oil service counter reset
		Powertrain control module	Injector replacement
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Fuel prime routine
		Powertrain control module	Service interval reset
		Powertrain control module	Adaption clear
		Powertrain control module	Rest of world - Service interval options
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Transmission control module	Adaption clear
		Anti-lock Braking System	Brake bleed
		Anti-lock Braking System	Yaw Rate sensor calibration
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Sunroof calibration
		Body control module	Valet mode reset
		Body control module	Steering column calibration
		Heating ventilation and air conditioning control module	Evaporator and heater test
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Steering angle sensor module	Steering wheel angle sensor calibration
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Auxiliary heater control module	Auxiliary heater priming routine
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Driver's seat module	Seat entry/exit enable
		Passenger's door module	Passenger's door window glass calibration
		Rear differential control module	Control module calibration
		Restraints occupant classification system module	Seat cushion replacement
		Headlamp Control Module	Headlamp control module system calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Sunroof calibration
		Body control module	Tire pressure monitoring tire pressure sensor test
		Steering angle sensor module	Steering wheel angle sensor calibration
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
Parking brake control module	Longitudinal accelerometer sensor calibration		
Parking brake control module	Parking brake unjam procedure		
Auxiliary heater control module	Auxiliary heater fuel delivery test		
Transfer case control module	Absolute position sensor replacement		
Restraints occupant classification system module	Seats - Seat cover replacement		
Headlamp Control Module	Headlamp control module system calibration		
Keyless vehicle module	Check passive keys enabled		
Audio amplifier module	DVD region counter reset		
Image processing module B	Camera auto learn routine		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Discovery 4	2012-2013	Powertrain control module	Oil service counter reset
		Powertrain control module	Rest of world - Service interval options
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Fuel prime routine
		Anti-lock Braking System	Brake bleed
		Anti-lock Braking System	Yaw Rate sensor calibration
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Sunroof calibration
		Heating ventilation and air conditioning control module	Evaporator and heater test
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Steering angle sensor module	Steering wheel angle sensor calibration
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Longitudinal accelerometer sensor calibration
		Parking brake control module	Parking brake unjam procedure
		Auxiliary heater control module	Auxiliary heater priming routine
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Driver's seat module	Seat entry/exit enable
		Passenger's door module	Passenger's door window glass calibration
		Rear differential control module	Control module calibration
		Restraints occupant classification system module	Seat cushion replacement
		Headlamp Control Module	Headlamp control module system calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Service interval reset
		Ride level control module	Air suspension height calibration
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Sunroof calibration
		Body control module	Tire pressure monitoring tire pressure sensor test
		Steering angle sensor module	Steering wheel angle sensor calibration
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
Parking brake control module	Longitudinal accelerometer sensor calibration		
Parking brake control module	Parking brake unjam procedure		
Auxiliary heater control module	Auxiliary heater fuel delivery test		
Transfer case control module	Absolute position sensor replacement		
Restraints occupant classification system module	Seats - Seat cover replacement		
Headlamp Control Module	Headlamp control module system calibration		
Keyless vehicle module	Check passive keys enabled		
Audio amplifier module	DVD region counter reset		
Image processing module B	Camera auto learn routine		
2014 -		Powertrain control module	Diesel fueling adaption re - initialization
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Rest of world - Service interval options
		Powertrain control module	Fuel Lift Pump
		Powertrain control module	Adaption clear
		Powertrain control module	Fuel prime routine
		Powertrain control module	Adaption clear
		Powertrain control module	Pilot correction learning
		Anti-lock Braking System	Yaw Rate sensor calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Vehicle reset
		Ride level control module	Air suspension deflation
		Ride level control module	Air suspension enable
		Ride level control module	Set/un - set air suspension manufacturing/freeze mode
		Ride level control module	Set/un - set air suspension tight tolerance mode (headlamp setting)
		Ride level control module	Set/un - set air suspension geometry set - up
		Body control module	Sunroof calibration
		Body control module	Tire pressure sensor replacement
		Body control module	Valet mode reset
		Body control module	Steering column calibration
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Transportation mode
		Body control module	Verify Keys
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Steering angle sensor module	Steering wheel angle sensor calibration
		Parking brake control module	Drive the parking brake to the mounting position
		Parking brake control module	Drive the parking brake to the latching position
		Parking brake control module	Parking brake unjam procedure
		Parking brake control module	Longitudinal accelerometer calibration
		Auxiliary heater control module	Auxiliary heater priming routine
		Gateway module	Battery replacement
		Gateway module	Quiescent current control module internal check
		Driver's seat module	Driver's seat calibration
		Driver's seat module	Seat entry/exit enable
		Rear differential control module	Control module calibration
		Restraints occupant classification system module	Seats - Seat cover replacement
		Headlamp Control Module	Headlamp control module system calibration
		Keyless vehicle module	Check all antennas
		Keyless vehicle module	Check passive keys enabled
		Keyless vehicle module	Recover programmed keys
		Audio amplifier module	Calibrate dynamic volume control
Image processing module B	Camera auto learn routine		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List			
			System Supported	Basic Function		
Range Rover Evoque	2012-2013	Engine	✓	✓		
		Transmission control module	✓	✓		
		ABS control module	✓	✓		
		Restraints control module	✓	✓		
		Instrument cluster control module	✓	✓		
		Adaptive damping control module	✓	✓		
		Body control module	✓	✓		
		Parking brake control module	✓	✓		
		Parking assist control module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Gear shift module	✓	✓		
		Gear shift module B	✓	✓		
		Steering angle sensor module	✓	✓		
		Restraints occupant classification system module	✓	✓		
		Power steering control module	✓	✓		
		Auxiliary heater control module	✓	✓		
		Rear differential control module	✓	✓		
		All terrain control module	✓	✓		
		Headlamp control module	✓	✓		
		Headlamp control module B	✓	✓		
		Driver's door module	✓	✓		
		Driver's seat module	✓	✓		
		Passenger's door module	✓	✓		
		Passenger's seat module	✓	✓		
		Rear gate/trunk module	✓	✓		
		Side object detection control module-Right	✓	✓		
		Side object detection control module-Left	✓	✓		
		Vehicle immobilizer control module	✓	✓		
		Image processing module B	✓	✓		
		Keyless vehicle module	✓	✓		
		Navigation control module	✓	✓		
		Audio head unit	✓	✓		
		Front controls interface module B(front audio control panel)	✓	✓		
				Front control/display interface module(high level display front)	✓	✓
				Audio amplifier module	✓	✓
				Audio front control module	✓	✓
				Digital audio broadcast module	✓	✓
				Rear entertainment control module	✓	✓
				Satellite audio unit module	✓	✓
				Television module	✓	✓
			2014	Engine	✓	✓
				Transmission control module	✓	✓
	ABS control module	✓		✓		
	Restraints control module	✓		✓		
	Instrument cluster control module	✓		✓		
	Adaptive damping control module	✓		✓		
	Body control module	✓		✓		
	Parking brake control module	✓		✓		
	Parking assist control module	✓		✓		
	Heating ventilation and air conditioning control module	✓		✓		
	All wheel drive control module	✓		✓		
	General proximity sensor module	✓		✓		
	Speed control module	✓		✓		
	Telematic control unit module	✓		✓		
	Gateway module	✓		✓		
	Gear shift module	✓		✓		
	Steering angle sensor module	✓		✓		
	Restraints occupant classification system module	✓		✓		
	Power steering control module	✓		✓		
	Auxiliary heater control module	✓		✓		
	Vehicle immobilizer control module	✓		✓		
	All terrain control module	✓		✓		
	Headlamp control module	✓		✓		
	Headlamp control module B	✓		✓		
	Driver's door module	✓		✓		
	Driver's seat module	✓		✓		
	Passenger's door module	✓		✓		
	Passenger's seat module	✓		✓		
	Rear gate/trunk module	✓		✓		
	Head up display	✓		✓		
	Connect and view module	✓		✓		
	Head-up display cooling fan module	✓		✓		
	Side object detection control module-Left	✓		✓		
	Side object detection control module-Right	✓		✓		
	Image processing module B	✓		✓		
	Keyless vehicle module	✓		✓		
	Navigation control module	✓		✓		
	Audio head unit	✓		✓		
	Front controls interface module 'B' (front audio control panel)	✓		✓		
		Front control/display interface module(high level display front)		✓	✓	
		Audio amplifier module		✓	✓	
		Audio front control module		✓	✓	
		Digital audio broadcast module	✓	✓		
		Navigation control module	✓	✓		
		Rear entertainment control module	✓	✓		
		Satellite audio unit module	✓	✓		
		Television module	✓	✓		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Range Rover Evoque	2012 - 2013	Powertrain control module	Fuel prime routine
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Injector valve test
		Powertrain control module	Purge valve self test
		Powertrain control module	Adaptive fuel trim display
		Powertrain control module	Oil service counter reset
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Injector replacement
		Powertrain control module	Idle speed - Adjustment
		Powertrain control module	Display injector correction factors
		Powertrain control module	Service interval reset
		Powertrain control module	Adaption clear
		Transmission control module	Transmission control module oil counter reset
		Transmission control module	Adaption clear
		Anti-lock Braking System	Steering wheel angle sensor calibration
		Anti-lock Braking System	Longitudinal accelerometer sensor calibration
		Anti-lock Braking System	Lateral accelerometer calibration
		Anti-lock Braking System	Pressure sensor calibration
		Anti-lock Braking System	Roll rate sensor calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Service interval reset
		Instrument cluster control module	Vehicle reset
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Valet mode reset
		Body control module	Tire pressure monitoring tire pressure sensor test
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Re - program all stepper motors
		Parking brake control module	Parking brake pad replacement - Release to service position
		Parking brake control module	Parking brake pad replacement - Exit maintenance mode application
		Parking brake control module	Parking brake activation
		Parking brake control module	Longitudinal accelerometer calibration
		Parking brake control module	Brake calliper replacement assembly test
		Auxiliary heater control module	Auxiliary heater priming routine
		Auxiliary heater control module	Auxiliary heater activation test
		Driver's door module	Driver's door window glass calibration
		Adaptive damping control module	Air suspension height calibration
		Restraints occupant classification system module	Seats - Seat cover replacement
		Headlamp Control Module	Headlamp control module system calibration
		Keyless vehicle module	Check all antennas
		Keyless vehicle module	Recover programmed keys
		Audio amplifier module	DVD region counter reset
		Audio amplifier module	Calibrate dynamic volume control
Rear gate/trunk module	Tailgate/trunk calibration		
Image processing module B	Camera auto learn routine		
Audio front control module	Navigation reset		
Side object detection control module - Left	Side object detection mode history		
Keyless vehicle module	Check passive keys enabled		
Range Rover Evoque	2014 - 2015	Powertrain control module	Fuel prime routine
		Powertrain control module	Throttle valve actuator replacement
		Powertrain control module	Reset water in fuel detection
		Powertrain control module	Exhaust gas recirculation valve
		Powertrain control module	Throttle valve actuator
		Powertrain control module	Oxygen sensor
		Powertrain control module	Oxidation catalyst
		Powertrain control module	Injector replacement
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement
		Powertrain control module	Diesel fueling adaption re - initialization
		Powertrain control module	Fuel Lift Pump
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Idle speed - Adjustment
		Powertrain control module	Turbine shut - off valve
		Powertrain control module	Oil change reset
		Anti-lock Braking System	Steering wheel angle sensor calibration
		Anti-lock Braking System	Pressure sensor calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Ride level control module	Air suspension height calibration
		Body control module	Tire pressure sensor replacement
		Body control module	Valet mode reset
		Body control module	Tire pressure monitor sensor identification display
		Body control module	Fuel pump supply - Enable/disable
		Body control module	Transportation mode
		Body control module	Roof blind calibration
		Body control module	Verify Keys
		Heating ventilation and air conditioning control module	Actuators end stop detection
		Heating ventilation and air conditioning control module	Stepper motor initialisation
		Heating ventilation and air conditioning control module	Re - program all stepper motors
		Heating ventilation and air conditioning control module	Seat climate control module calibration
		Heating ventilation and air conditioning control module	Run in air conditioning compressor
		Heating ventilation and air conditioning control module	Climate seat unlock
		Heating ventilation and air conditioning control module	Reset air conditioning compressor
		Parking brake control module	Parking brake pad replacement - Release to service position
		Parking brake control module	Parking brake pad replacement - Exit maintenance mode application
		Parking brake control module	Parking brake activation
		Parking brake control module	Longitudinal accelerometer calibration
		Passenger's seat module	Power steering soft - lock end stops reset routine
		Auxiliary heater control module	Auxiliary heater priming routine
		Gateway module	Battery replacement
		Gateway module	Quiescent current control module internal check
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Passenger's door module	Passenger's door window glass calibration
		Adaptive damping control module	Air suspension height calibration
		Speed control module	Speed control alignment
		Restraints occupant classification system module	Seats - Seat cover replacement
Headlamp Control Module	Headlamp control module system calibration		
Keyless vehicle module	Check all antennas		
Keyless vehicle module	Check passive keys enabled		
Keyless vehicle module	Recover programmed keys		
Audio amplifier module	Calibrate dynamic volume control		
Rear gate/trunk module	Tailgate/trunk calibration		
Image processing module B	Camera auto learn routine		
Anti-lock Braking System	Brake Bleeding		
Anti-lock Braking System	ECU Replacement		

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Discovery Sport	2015 - 2016	ABS control module	✓	✓
		All wheel drive control module	✓	✓
		Body control module	✓	✓
		Speed control module	✓	✓
		Gear shift module	✓	✓
		Gateway module	✓	✓
		Headlamp control module	✓	✓
		Instrument cluster control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Powertrain control module	✓	✓
		Restraints control module	✓	✓
		Transmission control module	✓	✓
		Telematic control unit module	✓	✓
		Tire pressure monitor module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Adaptive damping control module	✓	✓
		All terrain control module	✓	✓
		General proximity sensor module	✓	✓
		Image processing control module A	✓	✓
		Parking assist control module	✓	✓
		Power steering control module	✓	✓
		Steering angle sensor module	✓	✓
		Driver's door module	✓	✓
		Driver's (side) rear door module	✓	✓
		Driver's seat module	✓	✓
		Keyless vehicle module	✓	✓
		Passenger's door module	✓	✓
		Passenger's (side) rear door module	✓	✓
		Passenger's seat module	✓	✓
		Rear gate / trunk module	✓	✓
		Auxiliary heater control module	✓	✓
		InControl Touch audio head unit	✓	✓
		Head-up display cooling fan module	✓	✓
		Connect and view module	✓	✓
		Front control/display interface module (high level display front)	✓	✓
		Head up display	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		Image processing module B	✓	✓
		Navigation control module	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
		Deployable towbar control module	✓	✓
		Audio amplifier module	✓	✓
		Audio front control module	✓	✓
		Digital audio broadcast module	✓	✓
		Rear entertainment control module	✓	✓
		Satellite audio unit module	✓	✓
Television module	✓	✓		
	2017-	ABS control module	✓	✓
		All wheel drive control module	✓	✓
		Body control module	✓	✓
		Speed control module	✓	✓
		Gear shift module	✓	✓
		Gateway module	✓	✓
		Headlamp control module	✓	✓
		Instrument cluster control module	✓	✓
		Restraints occupant classification system module	✓	✓
		Powertrain control module	✓	✓
		Restraints control module	✓	✓
		Transmission control module	✓	✓
		Telematic control unit module	✓	✓
		Tire pressure monitor module	✓	✓
		Vehicle immobilizer control module	✓	✓
		All terrain control module	✓	✓
		General proximity sensor module	✓	✓
		Image processing control module A	✓	✓
		Parking assist control module	✓	✓
		Power steering control module	✓	✓
		Steering angle sensor module	✓	✓
		Adaptive damping control module	✓	✓
		InControl Touch audio head unit	✓	✓
		Head-up display cooling fan module	✓	✓
		Head up display	✓	✓
		Heating ventilation and air conditioning control module	✓	✓
		InControl Touch Pro infotainment master controller	✓	✓
		Image processing module B	✓	✓
		Side object detection control module - Left	✓	✓
		Side object detection control module - Right	✓	✓
		InControl Touch Pro audio amplifier module	✓	✓
		InControl Touch Pro infotainment slave controller	✓	✓
		Driver's door module	✓	✓
		Driver's (side) rear door module	✓	✓
		Driver's seat module	✓	✓
		Keyless vehicle module	✓	✓
		Passenger's door module	✓	✓
		Passenger's (side) rear door module	✓	✓
		Passenger's seat module	✓	✓
		Rear gate / trunk module	✓	✓
		Deployable towbar control module	✓	✓

Recovery System Coverage V4.0

Vehicle Information			Coverage List	
Model	Year	Vehicle System	System Supported	Basic Function
Freelander 1	2001 -2006	TEVES ATE MK20/MK25 ABS	✓	✓
		SIEMENS AIRBAG 1	✓	✓
		EWS 3D IMMOBILISER	✓	✓
		SAWDOC IMMOBILISER	✓	✓
		LUCAS 27VT CCU	✓	✓
		HELLA CRUISE CONTROL	✓	✓
		SIEMENS MS43 KV6 EMS (NAS Only)	✓	✓
		WEBASTO FUEL BURNING HEATER	✓	✓
		INSTRUMENT PACK	✓	✓
		JATCO AUTO BOX	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Freelander 1	1997 - 2001	Engine(KV6 (NAS Only))	Immobilisation Learn
		Engine(KV6 (NAS Only))	Reset Adaptions
		Engine(KV6 (NAS Only))	Idle Speed Adjust
		Engine(KV6 (NAS Only))	Programming History
		Transmission	ECU Checks & Renewal
		Anti-lock Braking System	ECU Renewal
		Anti-lock Braking System	Brake Bleeding
		Anti-lock Braking System	Calibrate 'G' Sensor
		Anti-lock Braking System	Vac Fill Valve Sequence
		Airbag	Display ECU Data
		Airbag	Renew ECU
		Alarms/Security	ECU Renewal
		Alarms/Security	Synchronise Immobilisation
		Alarms/Security	Identify Key
		Alarms/Security	Key Store
		Alarms/Security	Key Programming
		Body Control	ECU Renewal
		Body Control	Plip Programming
		Body Control	Volumetric Settings
		Cruise Control	Tune Information
		Cruise Control	Last Shut Off
		Fuel Burning Heater	Set CO2 Level
		Fuel Burning Heater	Prime System
		Instrumentation	ECU Renewal
		Instrumentation	NAS AAT Information
		Instrumentation	NAS/Canada OAT Information
		Transmission	ECU Checks & Renewal
		Powertrain control module	Adaption clear
		Powertrain control module	Fuel prime routine
		Powertrain control module	Throttle valve actuator replacement

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List			
			System Supported	Basic Function		
Freelander 2	2007-2010	Engine	✓	✓		
		AT	✓	✓		
		ABS	✓	✓		
		SRS	✓	✓		
		IP	✓	✓		
		BCM	✓	✓		
		HCM	✓	✓		
		Terrain	✓	✓		
		Driver's door module	✓	✓		
		Passenger's door module	✓	✓		
		Driver's seat module	✓	✓		
		Infotainment control module	✓	✓		
		Rear differential control module	✓	✓		
		Steering angle sensor module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Parking assist control module	✓	✓		
		Auxiliary heater control module	✓	✓		
		Restraints occupant classification system module	✓	✓		
		Trailer module	✓	✓		
		Transmission control module	✓	✓		
		Instrument cluster control module	✓	✓		
		Satellite audio unit module	✓	✓		
		Audio amplifier module	✓	✓		
		Front control/display interface module(high level display front)	✓	✓		
		Audio front control module	✓	✓		
		Cellular telephone control module(bluetooth telephone module)	✓	✓		
			2011-2012	Engine	✓	✓
				AT	✓	✓
				ABS	✓	✓
				SRS	✓	✓
				IP	✓	✓
				Heating ventilation and air conditioning control module	✓	✓
				Parking assist control module	✓	✓
Body control module	✓			✓		
Auxiliary heater control module	✓			✓		
Audio amplifier module	✓			✓		
Audio front control module	✓			✓		
All terrain control module	✓			✓		
Cellular telephone control module	✓			✓		
Digital audio broadcast module	✓			✓		
Digital audio control module C	✓			✓		
Driver's door module	✓			✓		
Driver's seat module	✓			✓		
Passenger's door module	✓			✓		
Front control/display interface module	✓			✓		
Headlamp control module	✓			✓		
Infotainment control module	✓			✓		
Navigation control module	✓			✓		
Trailer module	✓			✓		
Rear differential control module	✓			✓		
Restraints occupant classification system module	✓			✓		
Steering angle sensor module	✓			✓		
Satellite audio unit module	✓			✓		
	2013-2014			Engine	✓	✓
				Transmission control module	✓	✓
				ABS	✓	✓
				Restraints control module	✓	✓
				Instrument cluster control module	✓	✓
				Body control module	✓	✓
		Parking brake control module	✓	✓		
		Parking assist control module	✓	✓		
		All terrain control module	✓	✓		
		Headlamp control module	✓	✓		
		Restraints occupant classification system module	✓	✓		
		Steering angle sensor module	✓	✓		
		Rear differential control module	✓	✓		
		Vehicle immobilizer control module	✓	✓		
		Heating ventilation and air conditioning control module	✓	✓		
		Auxiliary heater control module	✓	✓		
		Keyless vehicle module	✓	✓		
		Driver's door module	✓	✓		
		Driver's seat module	✓	✓		
		Passenger's door module	✓	✓		
		Front control/display interface module (high level display front)	✓	✓		
		Front controls interface module "B" (front audio control panel)	✓	✓		
		Audio head unit	✓	✓		
		Image processing module B	✓	✓		
		Audio amplifier module	✓	✓		
		Audio front control module	✓	✓		
		Digital audio broadcast module	✓	✓		
		Satellite audio unit module	✓	✓		
		Television module	✓	✓		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions	
Model	Year	System	Supported
Freelander 2	2007 - 2010	Powertrain control module	Boost pressure actuator replacement
		Powertrain control module	Diesel particulate filter dynamic regeneration
		Powertrain control module	Injector replacement
		Powertrain control module	Diesel fueling adaption re - initialization
		Powertrain control module	Exhaust gas recirculation replacement
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement
		Powertrain control module	Diesel particulate filter air temperature sensor replacement
		Powertrain control module	Diesel particulate filter replacement
		Powertrain control module	Diesel lambda sensor replacement
		Powertrain control module	Oil service counter reset
		Powertrain control module	Idle speed - Adjustment
		Powertrain control module	Display injector correction factors
		Powertrain control module	Adaption clear
		Powertrain control module	Boost pressure actuator replacement
		Transmission control module	Adaption clear
		Transmission control module	Gear selector sensor calibration
		Anti-lock Braking System	Lateral accelerometer calibration
		Anti-lock Braking System	Longitudinal accelerometer sensor calibration
		Anti-lock Braking System	Pressure sensor calibration
		Anti-lock Braking System	Roll rate sensor calibration
		Anti-lock Braking System	Yaw Rate sensor calibration
		Supplemental Inflatable Restraint System	Restraints build mode
		Instrument cluster control module	Service interval reset
		Instrument cluster control module	Fuel consumption units
		Instrument cluster control module	Message centre display contrast
		Body control module	Sunroof calibration
		Body control module	Security - Keyfob remote functionality
		Body control module	Tire pressure sensor replacement
		Body control module	Tire pressure monitor confirmation application
		Body control module	Battery replacement
		Body control module	Program keys
		Body control module	Transportation mode
		Body control module	Tire pressure monitor transmitter functionality
		Body control module	Crash status reset
		Heating ventilation and air conditioning control module	Humidity sensor replacement
		Heating ventilation and air conditioning control module	Seat heater module calibration
		Heating ventilation and air conditioning control module	Stepper motor replacement
		Auxiliary heater control module	Auxiliary heater activation test
		Auxiliary heater control module	Auxiliary heater fuel delivery test
		Driver's door module	Driver's door window glass calibration
		Driver's seat module	Driver's seat calibration
		Passenger's door module	Passenger's door window glass calibration
Restraints occupant classification system module	Seats - Seat cover replacement		
Headlamp Control Module	Headlamp control module system calibration		
Powertrain control module	Diesel particulate filter dynamic regeneration		

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions			
Model	Year	System	Supported		
Freelander 2	2011 - 2012	Powertrain control module	Diesel particulate filter replacement		
		Powertrain control module	Diesel fueling adaption re - initialization		
		Powertrain control module	Diesel particulate filter differential pressure sensor replacement		
		Powertrain control module	Injector replacement		
		Powertrain control module	Exhaust gas recirculation valve		
		Powertrain control module	Throttle valve actuator		
		Powertrain control module	Oxygen sensor		
		Powertrain control module	Oxidation catalyst		
		Powertrain control module	Idle speed - Adjustment		
		Powertrain control module	Adaption clear		
		Powertrain control module	Throttle valve actuator		
		Transmission control module	Gear selector sensor calibration		
		Transmission control module	Adaption clear		
		Anti-lock Braking System	Yaw Rate sensor calibration		
		Anti-lock Braking System	Lateral accelerometer calibration		
		Anti-lock Braking System	Longitudinal accelerometer sensor calibration		
		Anti-lock Braking System	Pressure sensor calibration		
		Anti-lock Braking System	Roll rate sensor calibration		
		Supplemental Inflatable Restraint System	Restraints build mode		
		Instrument cluster control module	Service interval reset		
		Instrument cluster control module	Fuel consumption units		
		Instrument cluster control module	Message centre display contrast		
		Body control module	Sunroof calibration		
		Body control module	Tire pressure sensor replacement		
		Body control module	Tire pressure monitor confirmation application		
		Body control module	Battery replacement		
		Body control module	Security - Keyfob remote functionality		
		Body control module	Program keys		
		Body control module	Crash status reset		
		Heating ventilation and air conditioning control module	Humidity sensor replacement		
		Heating ventilation and air conditioning control module	Seat heater module calibration		
		Heating ventilation and air conditioning control module	Stepper motor replacement		
		Auxiliary heater control module	Auxiliary heater priming routine		
		Driver's door module	Driver's door window glass calibration		
		Driver's seat module	Driver's seat calibration		
		Passenger's door module	Passenger's door window glass calibration		
		Headlamp Control Module	Headlamp control module system calibration		
		Powertrain control module	Injector valve test		
		Freelander 2	2013 -	Powertrain control module	Fuel Lift Pump
				Powertrain control module	Fuel prime routine
				Powertrain control module	Purge valve self test
				Powertrain control module	Service interval reset
				Powertrain control module	Throttle valve actuator replacement
				Powertrain control module	Diesel particulate filter dynamic regeneration
				Powertrain control module	Injector replacement
				Powertrain control module	Diesel particulate filter replacement
				Powertrain control module	Oil service counter reset
				Powertrain control module	Idle speed - Adjustment
				Powertrain control module	Display injector correction factors
				Powertrain control module	Diesel fueling adaption re - initialization
				Powertrain control module	Diesel particulate filter differential pressure sensor replacement
				Powertrain control module	Exhaust gas recirculation valve
				Powertrain control module	Oxygen sensor
				Powertrain control module	Oxidation catalyst
				Powertrain control module	Reset water in fuel detection
				Powertrain control module	Turbine shut - off valve
				Transmission control module	Transmission control module oil counter reset
				Transmission control module	Adaption clear
				Transmission control module	Gear selector sensor calibration
				Anti-lock Braking System	Steering wheel angle sensor calibration
				Anti-lock Braking System	Longitudinal accelerometer sensor calibration
				Anti-lock Braking System	Lateral accelerometer calibration
				Anti-lock Braking System	Pressure sensor calibration
				Anti-lock Braking System	Roll rate sensor calibration
				Supplemental Inflatable Restraint System	Restraints build mode
Instrument cluster control module	Service interval reset				
Instrument cluster control module	Vehicle reset				
Body control module	Tire pressure sensor replacement				
Body control module	Tire pressure monitor confirmation application				
Body control module	Tire pressure monitor sensor identification display				
Body control module	Valet mode reset				
Body control module	Battery replacement				
Body control module	Sunroof calibration				
Body control module	Fuel pump supply - Enable/disable				
Body control module	Verify Keys				
Heating ventilation and air conditioning control module	Stepper motor initialisation				
Heating ventilation and air conditioning control module	Actuators end stop detection				
Heating ventilation and air conditioning control module	Re - program all stepper motors				
Parking brake control module	Parking brake pad replacement - Release to service position				
Parking brake control module	Parking brake pad replacement - Exit maintenance mode application				
Parking brake control module	Longitudinal accelerometer calibration				
Parking brake control module	Brake caliper replacement assembly test				
Parking brake control module	Parking brake activation				
Auxiliary heater control module	Auxiliary heater priming routine				
Auxiliary heater control module	Auxiliary heater activation test				
Driver's door module	Driver's door window glass calibration				
Driver's seat module	Driver's seat calibration				
Passenger's door module	Passenger's door window glass calibration				
Restraints occupant classification system module	Seats - Seat cover replacement				
Headlamp Control Module	Headlamp control module system calibration				
Keyless vehicle module	Check all antennas				
Keyless vehicle module	Check passive keys enabled				
Audio amplifier module	DVD region counter reset				
Audio amplifier module	Calibrate dynamic volume control				
Audio front control module	Navigation reset				
Anti-lock Braking System	ECU Renewal				

Recovery System Coverage V4.0

Model	Year	Vehicle System	Coverage List	
			System Supported	Basic Function
Defender	1994-2006	ABS WABCO D TYPE	✓	✓
		LUCAS 10AS ALARM	✓	✓
		Lucas GEMS EMS	✓	✓
		14CUX (LUCAS HOTWIRE) EMS	✓	✓
		Engine	✓	✓
	2007-2010	ABS	✓	✓
		LUCAS 10AS ALARM	✓	✓
		Vehicle immobilizer control module	✓	✓
		Instrument pack	✓	✓
		Engine	✓	✓
	2011	ABS	✓	✓
		Vehicle immobilizer control module	✓	✓
		Instrument pack	✓	✓
		Engine	✓	✓
	2012	ABS control module	✓	✓
		Vehicle immobilizer control module	✓	✓
		Instrument cluster control module	✓	✓
		Engine	✓	✓

Recovery System Coverage V4.0 - Special Functions

Vehicle Information		Supported Special Functions			
Model	Year	System	Supported		
Defender	Up to 2007	Engine(TD5)	Security Status		
		Engine(TD5)	Read/Set Injector Codes		
		Engine(TD5)	Security Reprogram		
		Engine(TD5)	ECM Checks & Renewal		
		Engine(TD5)	Set 2/3 Track Pedal Pot		
		Anti-lock Braking System	Brake Bleeding		
		Anti-lock Braking System	ECU Renewal		
		10AS Security	Pip Programming		
		Defender	2007 - 2010	Powertrain control module	Pump replacement
				Powertrain control module	Speed limitation
Powertrain control module	Injector replacement				
Powertrain control module	Pilot correction learning				
Powertrain control module	Pre - delivery inspection				
Anti-lock Braking System	Brake Bleeding				
Anti-lock Braking System	ECU Renewal				
Instrument cluster control module	Speed limitation				
Instrument cluster control module	Tyre circumference				
Instrument cluster control module	Fuel tank volume				
Defender	2011	10AS Security	Pip Programming		
		Powertrain control module	Pump replacement		
		Powertrain control module	Speed limitation		
		Powertrain control module	Adaption clear		
		Powertrain control module	Diesel particulate filter dynamic regeneration		
		Powertrain control module	Injector valve test		
		Powertrain control module	Oil change reset		
		Powertrain control module	Diesel particulate filter reset		
		Powertrain control module	Exhaust gas recirculation throttle replacement reset		
		Powertrain control module	Adaption clear		
Powertrain control module	Fuel Lift Pump				